

## SECTION 08 38 00 - TRAFFIC DOORS

### PART 1 - GENERAL

#### 1.1 SUMMARY

A. Section includes:

1. **KROGER DIRECT BUY PROGRAM:** Owner supplied/Contractor installed.
  - a. The Kroger Company will supply the traffic doors.
    - 1) Double acting insulated traffic doors (rigid plastic).
    - 2) Double acting flexible traffic doors (flexible PVC).
  - b. Comply with requirements in Division 00 Section "General Conditions."
2. Contractor supplied items:
  - a. Bent steel and hollow metal frames.
  - b. Fasteners, supports, and other items not provided by Owner necessary for a complete installation.
3. Contractor installed items:
  - a. Traffic doors and frames.

#### 1.2 SUBMITTALS

- A. The Owner will provide the following submittals for the Contractor's review. The Contractor shall review and return submittals as specified in Division 00 Section "General Conditions."
1. Product Data: For each type and size of traffic door.
  2. Shop Drawings: Including a schedule of doors using same reference numbers for details and openings as those on Drawings

### PART 2 - PRODUCTS

#### 2.1 TRAFFIC DOORS

- A. Double Acting Insulated Rigid Plastic Traffic Doors: Refer to Division 01 Section "Vendor Contact List" for information on insulated rigid plastic traffic doors.
- B. Double Acting Flexible PVC Traffic Doors: Refer to Division 01 Section "Vendor Contact List" for information on flexible PVC traffic doors.

- C. Hollow Metal Frames for Double Acting Insulated Rigid Plastic Traffic Doors: Refer to Division 08 Section "Hollows Metal Doors and Frames" for information on hollow metal frames for traffic doors where indicated.
- D. Bent Plate Frames for Double Acting Flexible PVC Traffic Doors: Refer to Division 05 Section "Metal Fabrications" for information on metal bent plate frames for traffic doors where indicated.

### PART 3 - EXECUTION

#### 3.1 INSTALLATION

- A. General: Install traffic doors complete with frames, necessary hardware and accessories, anchors, inserts, and hangers in accordance with Shop Drawings and manufacturer's instructions.
- B. Install assemblies plumb level, and properly aligned.
- C. Lubricate, test and adjust traffic doors to operate easily, free from warp, twist, or distortion.
- D. Coordinate installation of bollards or wall stops with drawings.

END OF SECTION 08 38 00