

SECTION 10 21 13 - TOILET COMPARTMENTS

PART 1 - GENERAL

1.1 SUMMARY

A. Section includes:

1. **KROGER DIRECT BUY PROGRAM:** Owner supplied/Contractor installed.
 - a. The Kroger Company will supply the toilet compartments.
 - 1) Toilet Enclosures: Overhead braced, no-sightline system.
 - 2) Urinal Screens: Wall hung.
 - b. Comply with requirements in Division 00 Section "General Conditions."
2. Contractor supplied items:
 - a. Blocking, anchor, hardware, fasteners, and other items not provided by Owner necessary for a complete installation.
3. Contractor installed items:
 - a. Toilet compartments.

1.2 SUBMITTALS

- A. The Owner will provide the following submittals for the Contractor's review. The Contractor shall review and return submittals as specified in Division 00 Section "General Conditions."
1. Product Data: For each type of product indicated.
 2. Shop Drawings: Include plans, elevations, sections, details, and attachments to other work.

1.3 QUALITY ASSURANCE

- A. Fire-Test-Response Characteristics: Toilet compartments shall meet or exceed requirements for Class "B" Flame Spread Rating calculated according to ASTM E-84-91A. Provide a UL Class "B" Fire Rating Certification.

PART 2 - PRODUCTS

2.1 TOILET COMPARTMENTS

- A. Refer to Division 01 Section "Vendor Contact List" for contact information on toilet compartments.

PART 3 - EXECUTION

3.1 INSTALLATION

- A. General: Comply with manufacturer's written installation instructions. Install units rigid, straight, level, and plumb. Secure units in position with manufacturer's recommended anchoring devices.
 - 1. Maximum Clearances:
 - a. Between Pilasters and Panels: 1/2 inch (13 mm).
 - b. Between Panels and Walls: 1/2 inch (13 mm).
 - c. Between Pilaster and Walls: 3/4 inch (17 mm).
 - 2. Stirrup Brackets: Secure panels to walls and to pilasters with not less than three brackets attached at midpoint and near top and bottom of panel.
 - a. Locate wall brackets so holes for wall anchors occur in masonry or tile joints.
 - b. Align brackets at pilasters with brackets at walls.

3.2 ADJUSTING

- A. Hardware Adjustment: Adjust and lubricate hardware according to manufacturer's written instructions for proper operation. Set hinges on in-swinging doors to hold doors open approximately 30 degrees from closed position when unlatched. Set hinges on out-swinging doors to return doors to fully closed position.

END OF SECTION 10 21 13