

1. WHEN CASES ARE FED FROM LOOP PIPING, SUCTION STOP SOLENOIDS WILL BE ON REFRIGERATION CIRCUITS ON SALES FLOOR.
2. REFER TO PIPING DRAWINGS (R3, R4, R5) FOR EXACT LOCATIONS

1. REFER TO R-SERIES REFRIGERATION SHEETS.
2. REMOVE AND REINSTALL WIRELESS REFRIGERATION TEMPERATURE SENSORS AS DIRECTED BY KROGER.
3. UPON PROJECT CLOSEOUT, PROVIDE A FRAMED ARCHITECTURAL D-SIZE RECORD DRAWING, SUITABLE FOR WALL MOUNTING, DOCUMENTING THE INSTALLED ROUTING OF CASE CONTROLLER WIRING OVERLaid ON THE BUILDING PLAN.

1. WHEN CASES ARE FED FROM LOOP PIPING, SUCTION STOP SOLENOIDS WILL BE ON REFRIGERATION CIRCUITS ON SALES FLOOR.
2. REFER TO PIPING DRAWINGS (R3, R4, R5) FOR EXACT LOCATIONS



copyright © 2024